



NOTES:

- 1) COMPRESSED SHOULDER - NO BLOCKOUTS REQUIRED AROUND POST
- 2) STANDARD SHOULDER - BLOCKOUTS REQUIRED AROUND POST
- 3) THE PURPOSE OF THE NON-MOW IS TO PREVENT VEGETATION AROUND THE POST AND UNDER THE RAIL