

Setbacks in diagram for the S-51 bridge only. General setup applies to all bridges but distances for the other two bridges are specified in 2.2.2.



